

Client: _____	Designation: _____
<u>Device:</u> <input type="checkbox"/> Washing water sterilizer <input type="checkbox"/> _____	
<u>Type:</u> _____	
Serial number: _____	Technician: _____
Batch number: _____	Date: _____

## Maintenance - Checklist

Scope for all types of washing water sterilizers L500

Pos	Items - description	Work - check	carried out	
			without complaint	with complaint
Pos 1	Pipe connection	replacement of all flat seals, check all pipes for leaks	<input type="checkbox"/>	<input type="checkbox"/>
Pos 2	Dirt trap	cleaning or replacement of screens	<input type="checkbox"/>	<input type="checkbox"/>
Pos 3	Solenoid valve	check for leaks and function, replacement of seal(s) if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 4	Check valve	check for leaks and function, replace it if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 5	Heat exchanger	functional check performance testing	<input type="checkbox"/>	<input type="checkbox"/>
Pos 6	Switch cabinet and cabling	control of clamping connections	<input type="checkbox"/>	<input type="checkbox"/>
Pos 7	Contactors/relay	check for wear and function	<input type="checkbox"/>	<input type="checkbox"/>
Pos 8	Temperature sensor PT100	check and calibrate if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 9	Pressure switch	check	<input type="checkbox"/>	<input type="checkbox"/>
Pos 10	Pressure transmitter	check and calibrate if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 11	Printer documentation option	functional check	<input type="checkbox"/>	<input type="checkbox"/>
Pos 12	Steam generator	control of heating power check for leaks and function	<input type="checkbox"/>	<input type="checkbox"/>
Pos 13	Tank	cleaning of feed water valve and control for leaks	<input type="checkbox"/>	<input type="checkbox"/>
Pos 14	Feed pump	check for leaks performance testing	<input type="checkbox"/>	<input type="checkbox"/>

Pos	Items - description	Work - check	carried out	
			without complaint	with complaint
Pos 15	Safety valve	functional check, outlet pressure	<input type="checkbox"/>	<input type="checkbox"/>
Pos 16	Battery CPU/Display	check and replace if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 17	Pressure gauge	check and calibrate if necessary	<input type="checkbox"/>	<input type="checkbox"/>
Pos 18	Pressure boost pump	check for leaks, test performance and functional test	<input type="checkbox"/>	<input type="checkbox"/>
Pos 19	metering pump	replace the seal and hose	<input type="checkbox"/>	<input type="checkbox"/>
Pos 20	Lance - Calligator	clean and functional testing	<input type="checkbox"/>	<input type="checkbox"/>
Pos 21	Sterile filter	replace it	<input type="checkbox"/>	<input type="checkbox"/>
Pos			<input type="checkbox"/>	<input type="checkbox"/>

Comments to positions:

\_\_\_\_\_  
The user's signature

\_\_\_\_\_  
Date

\_\_\_\_\_  
Signature of the technician